

TV Brand **Codes**

ABEX	049
ADMIRAL	163, 078, 188
ADVENT	067, 073, 241
ADVENTURA	017
AIKO	115
AIWA	050, 075, 105, 158
ALLERON	193
AMARK	163
AMTRON	247
AKAI	043, 215, 090, 296, 302, 022, 282, 337, 309
ANAM NATIONAL	247, 243, 035, 219, 261
AOC	001, 033, 138, 305, 002, 071
APEX	021, 077, 052, 331, 211
ARCHER	163
ASPECT	143
AUDIOVOX	247, 306, 295
AXION	100, 214
BANG & OLUFSEN	179
BELCOR	001
BELL & HOWELL	191, 142, 161, 188
BENQ	196, 250, 198, 317
BLUESKY	285, 015
BRADFORD	247
BROKSONIC	097, 045, 182, 107, 184, 024
BROKWOOD	001
CANDLE	001, 138, 017, 110
CAPEHART	048
CCE	340
CELERA	021
CELEBRITY	215
CENTRIOS	153
CENTURION	138
CETRONIC	219
CHANGHONG	021, 211
CINERAL	115, 015
CITIZEN	001, 138, 247, 043, 147, 155, 045, 188, 110, 219, 115
CLAIRTONE	002
CLASSIC	021, 211, 219
CLP	009
CLP CLASSIC	020, 004, 006
COBY	322, 272
COLOR VOICE	162
COLORTYME	001, 138, 162
CONCERTO	001, 138
CONCIERGE	200

CONTEC 247, 216, 002, 219
CORNEA 166
CRAIG 247, 219
CROSLEY 221
CROWN 247, 219
CURTIS MATHES 191, 043, 174, 001, 138, 161, 142, 147, 133, 188, 034
CTX 163
CXC 247, 219
CYBERVISION 015
DAEWOO 174, 001, 138, 171, 033, 122, 246, 175, 141, 237, 159, 026, 169, 219, 115, 084,
162, 068, 111, 095, 139
DAYTRON 001, 138
DELL 157, 112, 228
DIAMOND VISION 181, 137, 224
DIGIMATE 293
DIGISTAR 306, 047, 120, 067, 099, 228, 313, 326, 333
DIMENSIA 191, 161
DISNEY 124, 045
DUKANE 143, 222
DUMONT 200, 004
DURABRAND 155, 045, 257, 053, 134, 104, 098, 283
DYNASTY 219
DYNEX 045, also see Insignia
ELEKTRA 188
ELECTROBAND 215, 002
ELECTROHOME 001, 138, 002, 243, 217
ELITE VIDEO 102
EMERSON 001, 138, 005, 045, 142, 193, 155, 247, 097, 141, 174, 181, 105, 264, 182, 237,
022, 107, 054, 079, 086, 026, 055, 080, 165, 192, 218, 190, 030, 003, 154, 037,
035, 085, 164, 218, 004, 036
ENVISION 001, 138, 008, 305
ESA 155
FISHER 142, 172, 130, 178, 216
FUJITSU 102, 193, 286
FUNAI 193, 155, 247, 105, 080, 219
FUTURETEC 247, 219
GATEWAY 060
GE 191, 093, 016, 001, 138, 005, 006, 161, 238, 243, 044, 034, 217, 220, 091
GIBRALTER 200, 001
GOLDSTAR 001, 138, 033, 105, 132, 216, 088, 169, 071
GO VIDEO HDT 100 186
GRADIENT 335, 001, 257, 318, 311
GRUNDY 193, 247
GUESTVISION 208
GVISION 276
HAIER 196, 077, 104, 098, 297
HALLMARK 011, 138

HARVARD 247
HEWLETT PACKARD 277, 269
HITACHI 118, 143, 229, 167, 222, 001, 138, 197, 327, 188, 216, 194, 096, 150, 202, 154,
105, 240
HISENSE 249, 233, 077, 287
HUGHES 109, 240, 213
HYUNDAI 273
ILO 128, 314, 271, 336, 070, 155
IMA 247
INFINITY 221, 131
IN FOCUS 161
INITIAL 314, 070, 280, 308
INSIGNIA 252, 155, 104, 045, 255, 067, 099, 303, 080, 140
INTEGRA 206
INTEQ 200
JANEIL 017
JBL 221
JCB 215, 215
JC PENNEY 191, 001, 033, 138, 043, 093, 147, 006, 161, 091, 110, 216, 034, 217, 164, 220
JENSEN 001, 138, 255
JVC 167, 058, 102, 144, 176, 106, 268, 216, 039, 089, 202
KAWASHO 001, 138, 215
KAYPANI 048
KEC 219, 247
KENWOOD 001, 138
KLH 021
KLOSS NOVABEAM 116, 017
KOGI 276
KONKA 247, 189, 057, 087, 062, 252, 239, 265, 140
KTV 247, 002, 190, 219, 168
KURAZAI 188
LASONIC 181, 137
LEGEND 067
LG 001, 166, 138, 033, 046, 228, 105, 132, 216, 088, 169, 071, 109, 240, 213
LIQUIDVIDEO 100, 125, 214
LODGENET 191, 235, 161, 188
LOEWE 209, 221
LOGIK 191, 161, 188
LUCE 038
LUXMAN 001, 138
LXI 191, 001, 138, 142, 221, 093, 147, 161, 105, 034
MAGNASONIC 193
MAGNAVOX 221, 001, 138, 260, 338, 078, 131, 080, 110, 116, 040, 202
MAJESTIC 191, 161, 188
MARANTZ 221, 206, 001, 138
MAXENT 060

MEDION 263, 128, 124
MEGATRON 001, 138, 143
MEI 002
MEMOREX 001, 138, 142, 193, 045, 191, 161, 292, 130, 184, 188
MGA 001, 033, 138, 193, 216, 217, 202, 178
MIDLAND 191, 200, 006, 093, 034
MINTEK 070, 271
MINUTZ 220
MITSUBISHI 033, 203, 193, 001, 138, 022, 217, 202, 178, 240
MONIVISION 059
MONTGOMERY WARD 191, 188, 161
MOTEVA 142, 335
MOTOROLA 163, 243, 135
MTC 001, 033, 138, 043, 147, 002
MULTITECH 247
MULTIVISION 009
MYRON & DAVIS 236
NAD 001, 138, 147, 049
NEC 206, 001, 033, 138, 243, 162, 042, 202
NETTV 060, 013
NEXXTECH 330, 099
NIKEI 219
NIKKO 001, 138, 115
NIKO 339
NORCENT 077, 246, 061
NTC 115
OLEVIA 294, 328, 316, 332, 291
ONCOMMAND 208
ONKING 219
ONWA 247, 219
OPTIMUS 177, 049, 023, 210
OPTOMA 301
OPTONICA 163, 042
ORION 200, 045, 036
PANASONIC 205, 123, 006, 177, 221, 023, 210, 108, 187, 243, 168
PHILCO 221, 001, 033, 138, 260, 189, 304, 116, 040, 202, 243, 110
PHILIPS 221, 020, 018, 129, 051, 076, 103, 001, 155, 260, 156, 180, 196, 310, 275, 131,
080, 243, 110, 116, 040, 064, 091, 0202, 240
PHILIPS MAGNAVOX 221, 020, 103, 260, 078, 131
PILOT 001
PIONEER 049, 206, 222, 001, 138, 170, 154, 027
PIVA 279
PLANAR 292
POLAROID 233, 259, 255, 306, 289, 140
PORTLAND 001, 033, 138, 122, 174
PRECISION 072
PRICE CLUB 043

PRIMA 306, 047, 067, 099, 073
PRINCETON GRAPHICS 163, 146
PRISM 006
PROSCAN 191, 093, 034, 161, 231, 258, 081, 138
PROTON 234, 001, 138, 312, 251, 048
PROTRON 074
PROVIEW 293, 298, 278, 288
PULSAR 294
QUASAR 200, 001, 205, 123, 006, 177, 221, 023, 210, 243
RADIO SHACK 168, 191, 001, 114, 142, 247, 177, 138, 105, 238, 161, 216, 192
RCA 219, 042, 191, 001, 114, 006, 010, 171, 225, 093, 149, 207, 033, 138, 243, 034,
217, 065, 253, 044, 154, 101, 127, 136
REALISTIC 081, 191, 001, 114, 142, 247, 177, 138, 161, 105, 216, 192, 219
RHAPSODY 042
RUNCO 002, 200, 206
SAMPO 199, 013, 060, 001, 138, 048, 216
SAMSUNG 043, 090, 063, 147, 083, 138, 001, 033, 041, 232, 242, 133, 216, 034, 169, 011,
066, 266, 160
SAMSUX 138
SAMTRON 043
SANSUI 045, 184
SANTECA 019
SANYO 142, 092, 172, 001, 130, 216, 119, 178
SCEPTRE 151, 331
SCOTCH 001, 138
SCOTT 001, 138, 193, 247, 003, 036, 219
SEARS 191, 221, 142, 193, 043, 001, 138, 093, 147, 172, 155, 161, 226, 145, 024, 080,
216, 034, 178
SELECTRON 329, 313, 321
SEMP 319
SHARP 145, 254, 248, 163, 001, 138, 078, 079, 056, 042, 227
SHOGUN 001
SIGNATURE 191, 161, 188, 245
SIMPSON 110
SONIC 002
SONY 121, 244, 215, 195, 185, 230, 26
SOVA 334, 281
SOYO 315, 324
SOUNDESIGN 001, 138, 193, 247, 110, 219
SPECTRA 181
SPECTRAVISION 262
SQUAREVIEW 155
SSS 011, 247, 219
STARLITE 247
STAR SIGHT 007
SUPRA 001, 223
SUPERSCAN 226, 145, 080

SUPERSONIC 032

SUPREMACY 017

SUPREME 215

SVA 077, 236

SYLVANIA 221, 001, 138, 045, 155, 260, 325, 105, 080, 134, 110, 116, 040, 202, 204, 212

SYMPHONIC 247, 155, 105, 080, 003

SYNTAX 294, 316, 332

TANDY 163

TATUNG 196, 128, 243

TECHNICS 006

TECHWOOD 001, 138, 006

TEKNIKA 191, 001, 033, 138, 193, 247, 043, 147, 177, 161, 017, 188, 110, 216, 219

TELECAPTION 094

TELERENT 191, 161, 188

TERA 001, 074

TEVION 128

TMK 001, 138

TOSHIBA 152, 126, 147, 173, 206, 043, 142, 042, 177, 183, 133, 024, 031, 216, 042, 094,
202, 109, 213

TRUTECH 307, 284, 323

TV EARS 000

UNIVERSAL 220, 091

VICTOR 167

VIDTECH 001, 033, 138

VIEWSONIC 161, 222, 270, 274

VIKING 017

VIORE 300

VIZIO 196, 320, 001

WARDS 191, 221, 001, 033, 138, 193, 161, 116, 040, 091, 042, 148, 220, 188, 110, 003

WESTINGHOUSE 256, 012, 290, 082

WHITE WESTINGHOUSE 171, 174, 122, 096, 288, 105, 159, 169

YAMAHA 177, 001, 033, 138

ZENITH 200, 138, 166, 117, 197, 122, 143, 201, 113, 199, 014, 258, 007, 001, 045, 078,
105, 053, 106, 237, 079, 131, 184, 025, 133, 245, 141, 188, 115, 029